## EASY ORDER SELECTION GUIDE—GENERAC LIQUID-COOLED PRODUCTS ONLY



To determine the correct product codes for a Commercial liquid-cooled generator and transfer switch follow the steps below. A product code is required to order. To place an order, e-mail or fax the product codes to your inside sales representative or place your order online. If you have questions, call1-888-Generac. Freight is FOB factory. Charges will be determined at the time of order.

	STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	STEP 6
	kW Ratings	Engine	Voltage	Fuel	Enclosure	Emission/Catalytic
	e.g. (45 kW = 045)	e.g. (6.8L = 68)	120/240 1ø = <b>A</b> 120/208 3ø = <b>G</b> 120/240 3ø = <b>J</b> 277/480 3ø = <b>K</b>	Natural Gas = <b>N</b> Propane Vapor = <b>V</b> Field Convertible to LP = *	Aluminum = A	Converter  No Catalyst = X  Catalyst &  A/F Ratio = C <sup>2</sup>
ALL PRODUCT CODES BEGIN WITH RG = 22-60 kW	22 <sup>1</sup>	2.4L @ 1800 RPM	A,G,J	N*	A	Х
	25¹	1.5L @ 3600 RPM	A,G,J	N*	A	Х
	271	2.4L @ 1800 RPM	A,G,J	N*	A	Х
	30¹	1.5L @ 3600 RPM	A,G,J	N*	A	Х
	32 <sup>3</sup>	2.4L @ 1800 RPM	A, G, J, K	N*	A	Х
	36 <sup>3</sup>	2.4L @ 3600 RPM	A, G, J, K	N*	A	Х
	38 <sup>3</sup>	2.4L @ 1800 RPM	A, G, J, K	N*	A	Х
	45	2.4L @ 3600 RPM	A, G, J, K	N*	A	X, C
	48	5.4L @ 1800 RPM	A, G, J, K	N*	A	С
	48	4.5L @ 1800 RPM	A, G, J, K	N*	A	Х
	60³	2.4L @ 3600 RPM	A, G, J, K	N, V	A	Х
ALL PRODUCT CODES BEGIN WITH QT= 70-150 kW	70	6.8L @ 1800 RPM	A, G, J, K	N, V	A	X, C
	80 <sup>3</sup>	5.4L @ 3600 RPM	A, G, J, K	N, V	A	Х
	100	6.8L @ 2300 RPM Gear Drive	A, G, J, K	N, V	A	С
	130	6.8L @ 3000 RPM Gear Drive	A, G, J, K	N, V	A	С
	150	6.8L @ 3600 RPM	A, G, J, K	N, V	A	С
SAMPLE R G	0 6 0	2 4	G	N	A	X
Û	Û	Û	Û	<u>û</u>	Û	<u>↑</u>

PRODUCT CODE (Enter on Order Form)

## TRANSFER SWITCHES

	STEP 1	STEP 2	STEP 3	STEP 4	STEP 5
SELECTION	Transfer Switch Used With	Switch Type	Amp Rating	Voltage	Enclosure Type
CRITERIA	Generator Controller	Non-Service Rated = <b>C¹</b> Service Entrance Rated = <b>W⁴</b> All 3ø = <b>№</b>	e.g. (200 Amp = 200)	120/240 1ø = <b>A</b>	NEMA 3R = <b>3</b>
	Nexus Controller = <b>RTS</b> or <b>RXS</b> or Evolution Controller			120/208 3ø = <b>G</b> 120/240 3ø = <b>J</b>	
	or Evolution Controller	7111 09 11		$277/480 \ 3\emptyset = \mathbf{K}^2$	
	RTS or RXS	C, W, N	100, 150³, 200, 300³,	A, G, J, K	3
For Standby Generators			400, 600 <sup>5</sup> , 800 <sup>5</sup>		
22 - 150 kW	SAMPLE				
	R T S	N	4 0 0	G	3
	$\hat{\mathbf{T}}$	Û	Û	<b>Û</b>	Û
PRODUCT CODE (Enter on Order Form)					
(Lines on Sidel Follis)				ш	ш

<sup>1 = 120/240 1</sup>ø

<sup>1 = 22 - 30</sup> kW - CARB emission compliant in State of California and City of Los Angeles and do not require a catalyst. Emission compliant in State of Massachusetts.

<sup>2 =</sup> Catalyst & A/F Ratio may not be available for all models required for California and Massachusetts. Contact your Generac representative for details on these emission requirements.

<sup>3 =</sup> Not available with catalyst. Units are not CARB Compliant and may not be sold in state of California, City of Los Angeles, and state of Massachusetts.

<sup>\* =</sup> Units are field convertible through 48 kW and are shipped for use with Natural Gas.

<sup>2 = 277/480 3</sup>ø phase only for 32-160 kW

<sup>3 = 150 &</sup>amp; 300 Amp only available in RXSW150A3 and RXSW300A3 configuration

<sup>4 = 1</sup>PH 100 - 400 Amp or 3 PH 100 - 200 Amp only

<sup>5 =</sup> RTSC and RTSN only

<sup>6 =</sup> RTS 3 PH non-service rated only